



10781

FIG. 266—STEERING SYSTEM—MODEL CJ-3B, CJ-5, CJ-6

- | | | |
|--------------------------------------|--------------------------|------------------------------------|
| 1—Frame Cross Tube (CJ-3B) | 10—Left Tie Rod Socket | 19—Washer |
| 2—Steering Bellcrank Bracket (CJ-3B) | 11—Left Steering Tie Rod | 20—Bellcrank Shaft |
| 3—Steering Bellcrank | 12—Left Tie Rod Socket | 21—Bearing Seal |
| 4—Front Axle Assembly | 13—Right Tie Rod Socket | 22—Nut |
| 5—Steering Connecting Rod | 14—Bellcrank Nut | 23—Lockwasher |
| 6—Steering Gear Arm | 15—Washer | 24—Right Steering Tie Rod |
| 7—Steering Gear | 16—Bolt | 25—Right Shaft and Universal Joint |
| 8—Left Steering Knuckle and Arm | 17—Bellcrank Bearing | 26—Right Steering Knuckle and Arm |
| 9—Left Shaft and Universal Joint | 18—Bearing Spacer | |